

PROMAC[®]

BX-834VS

Instruction Manual




CE


20181001

CAUTION: BEFORE USING THR MACHINE BE SURE TO READ THIS MANUAL

8. Drawing and parts list;



BX-834VS



1	BASE
1A	WATER TANK
1B	BASE COVER
1C	PUMP MOTOR
1D	ADAPTER
1E	CLAMP
1F	HOSE
1-S1	SCREW
1-S2	SCREW
2Z	COLUMN SET
2-S1	BOLT
2-S2	SPRING WASHER
5Z	TABLE BRACKET SET
8	WORM
9	TABLE HANDLE
9A	HANDLE BOLT
16	CLAMP HANDLE
18	TABLE
19	RACK
20	RACK RING
20A	RACK RING
22	HEAD BODY
22A	SIDE COVER
22B	SHAFT
22C	VALVE
22D	FIXING PLATE
22E	NOZZLE
22-S1	SCREW
22-S2	LEAD BOLT
22-S3	PIN
22-S4	SET SCREW
22-S5	HEX NUT
22-S6	SET SCREW
22-S7	BOLT
26	SHIFTER BAR
27	SHIFTER
29L	SLIDE BAR(L)
29S	SLIDE BAR(S)
29-S1	WASHER
31	MOTOR BASE PLATE
31-S1	SPRING WASHER
31-S2	HEX NUT
35Z	FEED SHAFT SET
35-S1	HEX NUT
40	FEED HANDLE
41	GRIP
43	DEPTH ROD
43A	HEX NUT
43Z	POSITION SET BRACKET SET
43-S2	WASHER
43-S3	E TYPE BUCKLE
47	SPRING CAP
52Z	SPINDLE SET
52A	SLEEVE
52-S1	HEX BOLT
52-S2	SPRING WASHER
53	RUBBER WASHER
54A	DRAW BAR
59Z	SPINDLE SLEEVE SET
59A	LOCK WASHER
62	SNAP RING
63	PULLEY NUT
64	SPINDLE PULLEY
65	TAPER ARBOR

66	DRILL CHUCK
67	DRILL SHIFTER
67A	FIXED ROD
68	MOTOR
68-S1	BOLT
68-S2	WASHER
68-S3	HEX NUT
69	MOTOR WIRE
73	MOTOR PULLEY
76	WIRE
76A	WIRE PLUG
78	SPEED CONTROLLER
78A	BRAKING RESISTOR
78B	RPM DISPLAY UNIT
78C	SPEED SENSOR
78-S1	SCREW
78-S2	SCREW
78-S3	SCREW
79B	RPM SWITCH RETAINER PLATE
79C	PROXIMITY SWITCH RETAINER PLATE
79D	SWITCH BRACKET
79E	BUSH
79-S1	SCREW
79-S2	SCREW
79-S3	WASHER
79-S4	SCREW
81	PULLEY COVER
81A	REAR PULLEY COVER
81B	GRAB HANDLES
81C	PLATE
81-S1	SCREW
81-S2	SCREW
81-S3	SCREW
81-S4	WASHER
81-S5	HEX NUT
89	V-BELT
91	ALLEN WRENCH
92	MICRO SWITCH
92-S1	SCREW
101D	MICRO SWITCH BASE
101Z	MICRO SWITCH BRACKET SET
101-S1	SCREW
101-S2	SCREW
102LZ	SAFETY GUARD SET
102A	SAFETY GUARD SLIDE
102-S1	SCREW
102-S2	LEAD BOLT
103Z	BRACKET ROD SET
103-S3	C-RING
103-S4	WASHER
103-S5	SCREW
104	EMERGENCY STOP SWITCH
104A	ON SWITCH
104B	RPM SWITCH
104C	CHANGE SWITCH
104E	CHANGE SWITCH
104F	OFF SWITCH
104G	FAULT LAMP
108	GENERAL SWITCH
108A	ALUMINUM STRIP
108B	FUSE STE
108C	CONTACTOR RELAY
108D	MAGNETIC SWITCH
108E	TRANSFORMER

108F	TERMINAL BLOCKS
108G	GROUNDING
108-S1	SCREW
109	WIRE TERMINAL PLATE
109A	GENERAL SWITCH BOX
109B	SWITCH BRACKET
109C	SWITCH BRACKET
109E	PROTECTOR CAP
109-S1	SCREW
109-S2	SCREW
109-S3	SCREW
109-S4	SCREW
110	STEEL BAR
111	MICRO SWITCH PLATE
111-S1	SCREW
111-S2	WASHER
112	MICRO SWITCH BODY
112A	MICRO SWITCH TRIGGER
112-S1	SCREW
114	MICRO SWITCH
114-S1	SCREW
115	MICRO SWITCH COVER
115-S1	SCREW
V105Z	WISE SET
V105A	SET SLIDER
V110	MOUNT PIECE
803	SWITCH COVER
803-S1	SCREW
OLB-A	LED Work Lamp
OLB-B	LED Work Lamp Switch
OLB-S1	HEX NUT
OLD	LED DRIVER