



JPT-10B

Planer & Thicknesser

707410M.....1~230V, 50-60Hz

PARTS LIST
ERSATZTEILLISTE
LISTE DE PIECES

Walter Meier (Tool) AG

Tämperlistrasse 5
CH-8117 Fällanden
Switzerland

Phone +41 44 806 47 48

Fax +41 44 806 47 58

jetinfo.eu@waltermeier.com


www.jettools.com




P- 707410M

2012-04


JPT-10B Planer & Thicknesser




JPT-10B Planer Table Assembly




JPT-10B Motor




JPT-10B Front Frame Assembly




JPT-10B Chain Drive Assembly




JPT-10B Front Cover Assembly




JPT-10B Cutterhead Guard Assembly




JPT-10B Dust Cover Assembly




JPT-10B Jointer Infeed Table Assembly




JPT-10B Jointer Outfeed Table Assembly (10")




JPT-10B Cutter Head/Feed Roller Assembly



JPT-10B Jointer Fence Assembly



JPT-10B Rear Frame and Cover Assembly



JPT-10B Planer & Thicknesser

Index No.	Part No.	Description	Size	Qty
1	JJP8BT-1	Chain Support Bracket		1
2	JJP8BT-2	Sprocket		1
3	JJP8BT-3	E-Clip	Ø6	1
4	TS-2361051	Lock Washer	M5	36
5	TS-1540031	Hex Nut	M5	7
6	TS-1550031	Flat Washer	M5	24
7	JJP8BT-7	Corner Sprocket		4
8	JJP10BT-8	Chain		1
9	JJP10BT-9	Base		1
10	JJP8BT-10	Infeed Pointer Label		1
11	TS-1502031	Socket Head Cap Screw	M5x12	3
12	JJP8BT-12	Driven Lead Screw		3
13	JJP8BT-13	Drive Lead Screw		1
14	JJP10BT-14	Extension Table		1
15	TS-1503021	Socket Head Cap Screw	M6x10	3
16	JPT10B-16	Cutterblock guard profile	LF2(5A02)	1
17	JPT10B-17	Rive		2
18	JJP10BT-18	Main Table		1
19	JJP8BT-19	Crank Arm		1
20	JJP8BT-20	Guide Rail		2
21	TS-1503041	Socket Head Cap Screw	M6x16	4
22	JPT10B-22	Socket Head Cap Screw	M5x20	1
23	JJP8BT-23	Knob Screw		1
24	JJP8BT-24	Knob		1
25	JJP8BT-25	Locking Handle		2
27	TS-1532032	Pan Head Machine Screw	M4x10	1
28	TS-2361041	Lock Washer	M4	1
29	JJP8BT-29	Pointer		1
31	TS-1540021	Hex Nut	M4	2
32	JJP8BT-32	Cord Clamp		1
33	TS-1532052	Pan Head Machine Screw	M4x16	2
34	JJP8BT-34	Cover		2
35	JJP8BT-35	Rear Support		1
36	JJP8BT-36	Self-Tapping Screw	ST4.2x10	10
37	JPT10B-37	Scale		1
38	TS-1502011	Socket Head Cap Screw	M5x8	13

JPT-10B Planer & Thicknesser

Index No.	Part No.	Description	Size	Qty
39	JJP8BT-39	Power Cord Protector		1
40	JJP8BT-40	Rear Support Cover		1
41	JJP8BT-41	Pin		2
42	JJP8BT-42	Self-Tapping Screw	ST4.2x20	4
43	JPT10B-43	Power Cord		1
44	JJP8BT-44	Screw		1
45	JJP8BT-45	Spring		1
46	TS-1550031	Flat Washer	M5	4
47	TS-2331051	Cap Nut	M5	4
48	JJP8BT-48	Thread Lock Bushing		4
49	JPT10B-49	Cantilever Knob		1
50	JJP8BT-50	Outfeed Table Spacer		2
51	JJP8BT-51	Infeed Table Spacer		4
52	JJP8BT-52	Bearing		1
53	JJP8BT-53	Spring		2
54	JJP8BT-54	Bushing Block		5
55	JJP8BT-55	Spring		1
56	JJP10BT-56	Roller		2
57	707411	Knife		2
59	JJP8BT-59	Pin		4
60	JJP10BT-60	Knife Gib		2
61	JJP8BT-61	Screw		14
62	JJP10BT-62	Cutter head		1
63	TS-1540041	Handle Nut	M6	5
63A	JPT10B-63A	Handle Nut.M6		1
64	JPT10B-64	Outfeed Table		1
65	TS-1550021	Flat Washer	M4	3
66	TS-1501041	Socket Head Cap Screw	M4x12	2
67	JJP8BT-67	Fence Support		1
68	TS-1550041	Flat Washer	M6	6
69	TS-2361061	Lock Washer	M6	7
70	TS-1482021	Hex Cap Screw	M6x12	2
71	JJP8BT-71	Fence Bracket		1
72	JJP8BT-72	Screw		2
73	TS-1503061	Socket Head Cap Screw	M6x25	2
74	JJP8BT-74	Washer		6

JPT-10B Planer & Thicknesser

Index No.	Part No.	Description	Size	Qty
75	JJP8BT-75	Locking Nut		1
76	JJP8BT-76	Angle Pointer		1
77	JJP8BT-77	Pin		1
78	JJP8BT-78	Shaft		1
79	JWBS10OS-110	Carriage Bolt	M6x16	1
80	JJP8BT-80	Hex Cap Screw	M4x15	2
81	JJP8BT-81	Angle Marked Fence Support		1
82	JJP10BT-82	Fence		1
83	JJP10BT-83	Hose Adapter		1
84	JJP10BT-84	Knob		2
85	JJP10BT-85	Dust Chute		1
86	JJP8BT-3	E-Clip	Ø6	2
87	JJP8BT-87	Pointer		1
88	JPT10B-88	Infeed Direction Label		1
89	TS-1533042	Pan Head Machine Screw	M5x12	4
90	JJP8BT-90	Knob		3
91	JJP10BT-91	Adjusting Rod		1
92	TS-1541031	Nylon Insert Lock Nut		2
93	JJP10BT-93	Shaft		1
94	JJP8BT-94	Bracket		1
95	JPT10B-95	Cushion Block		2
96	JPT10B-96	Self-Tapping Screw	ST4.2x6	2
97	JPT10B-97	Lock Bushing		1
98	JPT10B-98	Cutterblock guard assembly		1
99	JPT10B -99	Base for Cutterhead Guard		1
100	JPT10B -100	Locking Knob		1
101	JPT10B -101	Locking Knob		1
102	JPT10B -102	Cutterhead Guard		1
103	JPT10B -103	Lock Washer		1
104	JPT10B -104	Locking Block		1
105	JPT10B -105	Shaft		1
106	JPT10B -106	Shaft		1
107	JJP10BT-107	Shaft		1
108	JJP10BT-108	Shaft		1
109	JJP8BT-109	Washer		29
110	JJP8BT-110	Anti-Kickback Finger		56

JPT-10B Planer & Thicknesser

Index No.	Part No.	Description	Size	Qty
111	JJP8BT-111	Bearing Cover		1
112	JJP8BT-112	Bearing	6000-2Z	1
113	JJP8BT-113	Front Support		1
114	JJP8BT-114	Cut Depth Scale Label		1
115	JJP8BT-115	Spring		1
116	TS-1502021	Socket Head Cap Screw	M5x10	6
117	JJP8BT-117	Switch Mount		1
118	JJP8BT-118	Switch		1
119	JJP8BT-119	Pulley		1
120	JJP8BT-120	Belt	5PJ604	1
121	JJP8BT-121	Spacer		1
122	JJP8BT-122	Sprocket		2
123	JJP8BT-123	Socket Head Cap Screw	M6x15	2
124	JJP8BT-124	Drive Chain	(P=12.7) 36	1
125	JJP8BT-125	Gear		1
126	JJP8BT-126	Pulley		1
127	TS-1533062	Pan Head Machine Screw	M5x20	3
128	JJP8BT-128	Key		1
129	JJP8BT-129	Belt		1
130	JJP8BT-130	Shaft		2
131	JJP8BT-131	Front Support Cover		1
132	JJP8BT-132	JET Nameplate		1
133	JJP8BT-133	Key		1
134	JJP8BT-134	Washer		1
135	JJP8BT-135	Sprocket		1
136	JJP8BT-136	Square Spacer		1
137	JJP8BT-137	Gear		1
138	JJP8BT-138	Gear Bracket		1
139	JJP8BT-139	Spring		1
140	JJP8BT-140	Key		1
141	JJP8BT-141	Pan Head Machine Screw	M3x18	2
142	TS-2361031	Lock Washer	M3	2
143	TS-1550011	Flat Washer	M3	2
144	JJP8BT-144	Wire Clamp		1
145	JJP8BT-145	Wire		1
146	JPT10B-146	Motor Pulley		1

JPT-10B Planer & Thicknesser


Index No.	Part No.	Description	Size	Qty
147	JJP8BT-147	Screw		1
148	JJP8BT-148	Bracket		1
149	JJP8BT-149	Washer		1
150	TS-2361081	Lock Washer	M8	1
151	JJP8BT-151	Socket Head Cap Screw	M8x15	1
152	JPT10B-152	Motor Assembly 230V		1
153	JJP8BT-153	Cover		2
154	JJP8BT-154	Star Washer	M4	1
155	JJP8BT-155	Strain Relief		2
156	JJP8BT-156	Switch Box		1
157	TS-1533032	Pan Head Machine Screw	M5x10	2
158	JPT10B-158	Overload Switch	6A.	1
159	JJP8BT-159	Switch Box Cover		1
160	JJP8BT-160	Self-Tapping Screw	ST4.2x15	4
161	JJP8BT-161	Nut		1
162	JPT10B-162	Switch	KJD17F	1
163	JJP8BT-163	Shaft		1
164	JPT10B-164	Infeed Table		1
165	TS-1521051	Set Screw	M4x12	2
166		Cord Clamp		1
167		Motor Housing		1
168	JJP8BT-168	Brush Holder		2
169	JJP8BT-169	Carbon Brush		2
170	JJP8BT-170	Brush Cap		2
171		Bearing		1
172		Inductor		1
173		Stator Insulation Pan		1
174		Armature .		1
175		Stator		1
176		Stator Insulation Pan		1
177		Self-Tapping Screw	ST5x56	2
178	JJP8BT-178	Fan		1
179		Bearing		1
180	JJP8BT-180	Motor Cover		1
181	JPT10B-181	Switch Box Faceplate		1
182	JJP8BT-182	Jack Screw		4

JPT-10B Planer & Thicknesser

Index No.	Part No.	Description	Size	Qty
183	JJP8BT-183	Rivet	Ø3x10	4
185	JJP8BT-185	Lock Shaft 1		1
186	JPT10B-186	Cord Clamp		1
187	JPT10B-187	Fence End Cover 1		1
188	JPT10B-188	Fence End Cover 2		1
189	JPT10B-189	Lock Shaft 2		1
190	JPT10B-189	Rod		2
191	JPT10B-191	O-Ring		1
.....	708815	Push Block (not shown)		2
.....	JJP8BT-KSG	Knife/Blade Setting Gauge (not shown)		1

JPT-10B Planer & Thicknesser - Stand

Index No.	Part No.	Description	Size	Qty
1	JJP10BT-901	Stand Top Support, Short		2
2	JJP10BT-902	Leg		4
3	JJP10BT-903	Support Plate, Long		2
4	JJP10BT-904	Support Plate, Short		2
5	JJP10BT-905	Stand Top Support, Long		2
6	TS-1540041	Hex Nut	M6	24
7	TS-2361061	Lock Washer	M6	24
8	TS-1550041	Flat Washer	M6	24
9	708315-63	Carriage Bolt	M6x12	24
10	TS-1540041	Hex Nut	M6	4
11	TS-1550041	Flat Washer	M6	4
12	JJP10BT-912	Rubber Foot		4
13	TS-1482041	Hex Cap Screw	M6x20	4
14	TS-1550061	Flat Washer	M8	4
15	TS-2361081	Lock Washer	M8	4
16	TS-1504041	Socket Head Cap Screw	M8x20	4



JPT-10B**707410M****1~230V, 50-60Hz**

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
OL	overload cut-off	Überlastschuttschalter	déclencheur surcharge
LS1	limit switch	Positionsendschalter	micro
LS2	limit switch	Positionsendschalter	micro

Wiring diagram

