



DC-1200

DC-1200CK-M

DC-1200CK-T

Dust Collector

DC-1200.....10001057M1~230V, 50Hz

DC-1200.....10001057T 3~400V, 50Hz

DC-1200CK-M....10000078M1~230V, 50Hz

DC-1200CK-T....10000078T 3~400V, 50Hz

PARTS LIST



TOOL FRANCE SARL


9 Rue des Pyrénées, 91090 LISSES, France

www.jettools.com

P-10001057M/T, 100000078M/T, 19500117

2019-03

Parts Breakdown for DC-1200_DC-1200CK-M/T Dust Collector




Parts List for DC-1200_DC-1200CK-M/T Dust Collector

Index No.	Part No.	Description	Size	Qty.
1	DC1200-001	Caster	3"	4
2	DC1200-003	Nut	M6	6
3	DC1200-003	Washer	6	28
4	DC1200-004	Hex. Bolt	M6x10	28
5	DC1200-005	Base		1
6	DC1200-006	Hose	4"x2000	1
7	DC1200-007	Hose Clamp 4"	M100	2
8	DC1200-008	Cap		2
9	DC1200-009	Inlet Port		1
10	DC1200-010	Screw	M5x8	1
11	DC1200-011	Inlet Guard		1
12	DC1200-012	Packing		1
13	DC1200-013	Cap Screw	M6x20-L	1
14	DC1200-014	Washer		1
15	DC1200-015	Impeller		1
16	DC1200-016	Impeller Housing		1
17	DC1200-017	Washer	8	26
18	DC1200-018	Bolt	M8x16	18
19	DC1200-019	Washer		1
20	DC1200-020	Motor Base		1
21	DC1200-021	Hex. Nut	M8	4
22	DC1200-022	Wire Connector		1
23	DC1200-023	Wire		1
24	DC1200T-024	Motor 400V,50Hz, 3PH, P1=1.5kW complete assembly		1
	DC1200M-024	Motor 230V, 50Hz, 1PH, P1=1.5kW complete assembly		1
24-1	DC1200-024-1	Motor Fan Cover		1
24-2	DC1200-024-2	Motor Fan		1
24-3	DC1200-024-3	Capacitor 450V 50uf-- Capacitor for 230V		1
25	DC1200-025	Bolt	M8X25	4
26	DC1200-026	Key	A5x25	1
27	DC1200-027	Collector Bag		1
28	DC1200-028	Screw	ST4.2x12	2
29	DC1200T-029	Switch 400V 50Hz 3PH		1
	DC1200M-029	Switch 230V 50Hz 1PH		1
30	DC1200-030	Screw	ST4.2x16	4
31	DC1200-031	Switch Plate		1
32	DC1200-032	Packing		1
33	DC1200-033	Screw	M5x12	3
34	DC1200-034	Switch Box Base		1
35	DC1200-035	Hex. Nut	M5	3
36	DC1200-036	Packing		4
37	DC1200-037	Washer	10	4
38	DC1200-038	Hex. Bolt	M10x16	4
39	DC1200-039	Hose Tube	5"X750mm	1
40	DC1200-040	Collector		1
41	DC1200-041	Hose Clamp 5"	M125	2
42	DC1200-042	Bag Clamp		2
43	DC1200-043	Outlet		1
44	DC1200-044	Filter Bag		1
45	DC1200-045	Upper bag Support		1
46	DC1200-046	Collector Support		1
47	DC1200-047	Hex. Bolt	M6x20	6
48	DC1200-048	Hex. Wrench	5	1
49	DC1200-049	Wire		1
50	DC1200T-050	Plug 400V 50Hz 3PH		1
	DC1200M-050	Wire & Plug 230V 50Hz 1PH		1

Filter Assembly Part List for DC-1200CK-M/T Models

Stock No.: 19500117

Index No.	Part No.	Description	Size	Qty.
51	19500117	Cartridge 20/24 Filter (#101 thru 119)		1
101	DC1200CK-101	Filter Assembly (Include #102)		1
102	DC1200CK-102	Rubber Pad		1
103	DC1200CK-103	Support		1
104	DC1200CK-104	Self-Tapping Screw	ST4.8x16	4
105	DC1200CK-105	Handle		1
106	DC1200CK-106	Soft Grip Handle		2
107	DC1200CK-107	Socket Head Cap Screw	M6x10	1
108	DC1200CK-108	Ball Bearing	6201	1
109	DC1200CK-109	Hex Nut	M5	6
110	DC1200CK-110	Lock Washer	5	6
111	DC1200CK-111	Flat Washer	5	6
112	DC1200CK-112	Socket Head Cap Screw	M6x12	3
113	DC1200CK-113	Lock Washer	6	3
114	DC1200CK-114	Flat Washer	6	3
115	DC1200CK-115	Scraper		2
116	DC1200CK-116	Press Plate		6
117	DC1200CK-117	Shaft		1
118	DC1200CK-118	Pan Head Machine Screw	M5x12	6
119	DC1200CK-119	Lock Nut	M12	1
120	DC1200CK-119	Flat Washer	12	1




Wiring Diagram for DC-1200 / DC1200CK-M Dust Collector

	colour of strands	Litzenfarben	couleur des cordons
BK	Black	Schwarz	Noir
WH	White	Wei	blanc
BU	Blue	Blau	Bleu
BN	Brown	Braun	Brun
YE	Yellow	Gelb	Jaune
RD	Red	rot	rouge
GNYE	green-yellow	grn-gelb	vert-jaune

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	Condenser	Kondensator	Condensateur
OL	Overload cut-off	Überlastschutzschalter	Déclencheur surcharge

10001057M ~230V, 50Hz
10000078M ~230V, 50Hz



Wiring Diagram for DC-1200 / DC1200CK-T Dust Collector

10001057T 3~400V, 50Hz

10000078T 3~400V, 50Hz

3~400V 50Hz

